



Agenda[®]

Direction for Use

Usage table

Pest	Application method	Recommended dilution rate Agenda [®] : water	Recommended volume of finished solution
Termites	Pre-construction treatment by spraying.	240 ml : 10 L water	5 L / m ²
	Post construction treatment for buildings infested with termites by rodding* / trenching* or spraying.	240 ml : 10 L water	5 L / m ²

* Trenching: the method of digging a trench around the building and spraying the finished solution into it to produce a layer of protection.

* Rodding: the method of drilling holes in the floor or wall building by a punching machine, before spraying or pouring the finishes solution into these holes to produce a layer of protection. Ensure only 3 g of active ingredient is applied per linear meter when 'rodding'.

FOR MORE INFORMATION, READ PRODUCT LABEL BEFORE USE

Bayer Co. (Malaysia) Sdn Bhd (7563 M)
Tel: 03-6209 3088 Email: es.malaysia@bayer.com

